






Scientific Solutions For Fitness™

Owner's Operation Manual

TC1000 Series Intelli-Fit Climber



 Before using this product, read this manual and follow all safety rules and operating instructions. 

This page intentionally left blank

IMPORTANT!

The TC1000 machine has been delivered in the “SHIPPING MODE”, which helps save the internal 12V battery of this machine. It is important this mode be turned off. Please do the following steps:

Turning off the “Shipping Mode”

- (A) Climb onto the TC1000 and begin to pedal.
 - (B) Press the [Quick Start] key and begin a workout.
 - (C) After 5 seconds press the [Pause/Clear] key, then
 - (D) Press the [Stop] key to exit the program, then stop pedaling to let the machine power down.
- The “Shipping Mode” has now been turned off.




TABLE OF CONTENTS

SAFETY INFORMATION	1
INTRODUCTION	2
SPECIFICATIONS	3
SET-UP & INSTALLATION	4
PRODUCT OVERVIEW	5
KEYPAD FUNCTIONS	6
BIOMECHANICAL POSITIONING	7
ACCESSORIES	8
HEART RATE TRANSMITTER STRAP	9
PROGRAM INSTRUCTIONS	10 - 14
MAINTENANCE & SERVICE	15
WARRANTY	16 - 20
WARRANTY CARD	21

SAFETY INFORMATION

The purpose of safety symbols is to attract your attention to possible dangers. The safety symbols, and their explanations deserve your careful attention and understanding. The safety warnings do not, by themselves eliminate any danger. The instructions or warnings they give are not substitutes for proper accident prevention measures.

Look for these symbols to point out important safety precautions. It means attention! Your safety is involved.

WARNING

Failure to obey a safety warning **can** result in injury to yourself and others. Always follow the safety precautions to reduce the risk of personal injury.

CAUTION

Failure to obey a safety caution **can** result in injury to yourself and others. Always follow the safety precautions to reduce the risk of personal injury.

Read all instructions before using your SCIFIT exercise machine. Save these instructions for future reference.

Close supervision is necessary when the exercise machine is being used by or near children or individuals with disabilities. Keep children away from extended hand and foot supports.

Use the exercise machine only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

Never drop or insert any object into any opening.

Do not use outdoors or in a harsh environment where water is present (i.e. pool or spa areas).

INTRODUCTION

Thank you for your purchase of the SCIFIT TC1000 series stepper. We have incorporated the finest technology and ergonomic design into this machine to assist you in achieving your fitness goals. However, for your safety please adhere to the following recommendations before you begin to exercise.

The SCIFIT TC1000 is designed for Class "S" (Studio) applications. The intended uses are for Physical Conditioning and Strength Training. SCIFIT equipment is suitable for placement in fitness and recreational facilities. The TC1000 series has 200 levels of computer controlled resistance, which ensures that users of all fitness levels will be able to get a challenging but not overwhelming workout.

Consult Your Physician

Consult your physician or medical specialist before participating in any exercise program, especially if you are pregnant, or suffering from heart disease, respiratory disease, diabetes, hypertension, high blood pressure, elevated cholesterol, arthritis and any other diseases or physical complaints.

Adult Usage

SCIFIT equipment are designed and intended for adult usage and children of appropriate ages while being supervised. Young children should be kept a safe distance away from equipment.

Cool Down

To prevent muscle injuries and soreness, you should always cool down (at least 5 minutes) by doing a series of stretches after each workout.

CAUTION

Always stretch after a workout session to reduce the risk of personal injury. Failure to stretch properly may result in injury to yourself.

Guidelines for Healthy Adults The American College of Sports Medicine (ACSM) and the American Heart Association (AHA) are continuously updating guidelines and recommendations for physical activity.

The current basic recommendations from ACSM and AHA is:

Do moderately intense cardio 30 minutes a day, five days a week.

OR

Do vigorously intense cardio 20 minutes a day, three days a week.

AND

Do eight to ten strength-training exercises, eight to twelve repetitions of each exercise twice a week.

Moderate-intensity physical activity means working hard enough to raise your heart rate and break a sweat, yet still being able to carry on a conversation. It should be noted that to lose weight or maintain weight loss, 60 to 90 minutes of physical activity may be necessary. The 30 minute recommendation is for the average healthy adult to maintain health and reduce the risk for chronic disease.

To review the latest guidelines and recommendations, visit the American College of Sports Medicine website: www.acsm.org

WARNING

Stop exercising immediately if you feel nausea, dizziness, sharp pain, or any other physical discomfort. Failure to stop exercising can result in injury or death to yourself.

Train Intelligently



To ensure a future of good health, you should always eat well balanced meals, drink plenty of fluid/water during a workout, and stay fit by exercising intelligently. Always follow training guidelines that are specific for your own physical condition.

WARNING

Injuries to health may result from incorrect or excessive training. Failure to stop exercising can result in injury or death to yourself.

SPECIFICATION

Weight.....TC1000 - 182 lbs (83 Kg) unboxed.TC1000 - 262 lbs (119 Kg) boxed
Max User WeightMaximum - 375 lbs (170 Kg)Minimum - 100 lbs (45 Kg)
Power.....Self generating w/auto recharge battery back-up with standard Low Voltage AC adapter.
Resistance System.....TC1000 - Electromagnetic Self Generating Resistance
Programs.....Quick Start, Manual, 7 Pre-programmed Hills profiles, Heart Rate and Random
Usage Class.....Class S
WarrantyWithin U.S. & Canada 3 years parts, 1 year labor
Outside U.S. 3 years parts, no labor



SET-UP & INSTALLATION

Placement of Cardiovascular Machine: Position the unit in a location that has a stable and level sub-floor. Equipment should be positioned in a location that is not in direct sunlight, in areas of extreme temperature and humidity or where the equipment may be splashed with water or fluids. This machine is intended for indoor use only.

Equipment should be positioned with a safety perimeter of 40" or 1 meter around the unit.



⚠ WARNING

Failure to place the equipment on a stable and level sub-floor with a safety perimeter can result in injury to yourself and others.

Level Cardiovascular Machine

If the sub-floor is unlevel, the unit is equipped with leveling end caps. The front end caps are designed with the recess of end cap off centered. This allows you to rotate the endcap(s) to a position that will level the equipment. After adjustment, check and make sure end caps are fully seated against base frame tubes.

Offset Endcap




Proper Supervision

Close supervision is required when the exercise machine is being used by or near individuals with disabilities. Keep unsupervised children outside the safety perimeter.

Cleaning

Never clean the machine with organic solvents, alcohol or bleach based cleaners. To promote a healthy environment, wipe any sweat off of unit with a commercially manufactured wipe designed for the fitness industry, or a damp cloth.


PRODUCT OVERVIEW



KEYPAD FUNCTIONS

Workout Status Screen -

The LCD screen gives progressive real-time data of different categories during the workout.



BIOMECHANICAL POSITIONING

Body Positioning

Comfort is a key issue to obtain the most beneficial exercise, as a workout progresses the tendency will be to lean forward and use the handlebars for support. A straight upright body posture throughout the workout will result in a broader range of muscle recruitment.

Gripping the Handlebar (fig. 1)

The SCIFIT TC1000 has ergonomic grip handlebars that allow several gripping positions. Moving hand positions during a workout will help reduce stress points and upper body tension.

Contact and Wireless Heart Rate (fig. 2)

Heart rate monitoring on the TC1000 is provided in two ways:

1. The wireless method, which requires an optional transmitter chest strap (see page 9).
2. The contact method acquired by placing the hands on the metal CHR plates located at the top of the handlebars.

NOTE: If wearing a transmitter chest strap, this signal will override the contact heart rate signal.

Orthopedic Footbeds (fig. 3)

The large oversized cushioned footbeds of the SCIFIT TC1000 allows the user traction and comfort during a workout reducing stress on the body.

Safe Operating Workout Range (fig. 4)

The TC1000 has a 10.5" safe operating stepping zone without the user bottoming out (Foam bumper under the pedal hitting the ground) or topping out (Pedal arm hitting upper bumper inside the covers). Keeping within this zone will allow for a maximum workout.




fig.1




fig.2




fig.3




fig.4


CAUTION

Always follow medical professionals guidelines to reduce the risk of personal injury. Failure to follow their directions may result in injury to yourself.

ACCESSORIES


(optional) Heart Rate Chest Strap: 65190

Provides a continual real-time heart rate tracking during a workout.



(standard) AC Wall Pack: P4861 (Dom)


Provides continuous power to the machine when not in use.



(optional) AC Wall Pack: P3733 (Int'l)

Provides continuous power to the machine when not in use.

Note: Separate power cord is country dependent, contact SCIFIT product support



HEART RATE TRANSMITTER STRAP & CONTACT GRIPS

Uses of the Heart Rate Transmitter Strap

The optional wireless heart rate transmitter accessory is a useful device if you desire continuous feedback on your current heart rate during a workout. In addition, the TC1000 includes a Heart Rate Control program which requires use of the strap.

The Heart Rate Control program enables the user to setup a target heart rate. Through real-time monitoring of the user's heart rate, the console maintains the user's heart rate at or below this established target rate by decreasing the workload if the user's heart rate exceeds the target.

Activating & Deactivating Transmitter

Heart rate transmitter straps come in a variety of styles and manufacturers. To properly activate, follow the manufacturers instructions, then secure the strap to the chest. To deactivate the strap again follow the manufacturers instructions .

⚠ CAUTION

Always follow manufacturers instructions for proper care and use. Failure to follow manufacturers instructions may result in injury to yourself.



⚠ WARNING


Heart Rate monitoring systems may be inaccurate. If you feel faint, stop exercising immediately. Over exercising may result in serious injury or death.

Use of the Heart Rate Contact Grips

Simply grip the contact plates lightly (see figure below). After a short delay a pulse reading will appear on the screen. **If a heart rate transmitter strap is worn, it will override the contact pickup.**

The contact grips are not designed for use with SCIFIT's Heart Rate Control program. This program requires a steady, continuous telemetry signal which can not be provided using contract heart rate grips.

While the contact grips provide a good barometer for monitoring the users heart rate, they are not recommended for medical use where accuracy of monitoring is vital.



Calculating Target Heart Rate Zone

Your approximate **Maximum Heart Rate (MHR)** is equal to 220 minus your age. The upper limit of your target zone is equal to 0.85 times your MHR. The lower limit of your target zone is equal to 0.60 times your MHR.

For Example:

Your age is 40:

$$220 - 40 = 180$$

$$180 \times .85 = 153 \text{ (max MHR)}$$

$$180 \times .60 = 108 \text{ (min MHR)}$$

These values are based upon averages, always consult your physician to establish the proper Heart Rate Zone for your individual health condition.

PROGRAM INSTRUCTIONS

Programs

SCIFIT products have 200 levels of computer controlled resistance, ensuring that users of all fitness levels will be able to get a challenging but not overwhelming workout. Resistance levels are adjustable in .1 increments, making it easy for the user to track progress. SCIFIT products feature one of the highest resistance capabilities available on any cardio equipment.

SCIFIT products are self generated and have an extremely low starting resistance. One pedal movement or crank revolution activates the console and the screen will remain lit at the most minimal levels of movement.

SCIFIT products have a battery back up which will keep the screen lit for a short period after exercising or if the user stops. This varies between 0 seconds and 3 minutes depending on the "Set-Up" mode value.

If you prefer the console to always remain lit, an optional AC wall adapter can be plugged into the machine. This is common with Fit-Key Programs usage.

Manual Workout

Allows the user to set the intensity at any level. This level will not change unless the user manually increases or decreases the intensity using the [UP] or [DOWN] arrow keys.

Press **MANUAL** Then 

Time (mm:ss)	15:00
Level	1.0
Weight (lbs)	150

Adjust the workout time (maximum 99 min.)

with the   keys, then press 

Time (mm:ss)	15:00
Level	1.0
Weight (lbs)	150

Adjust the level intensity (maximum 20)

with the   keys, then press 

Time (mm:ss)	15:00
Level	1.0
Weight (lbs)	150

Enter the user weight (maximum 375 lbs/ 170 Kg)


with the   keys, then press  to begin workout.




PROGRAM INSTRUCTIONS

Hills Program

Allows the user to select from seven different Hill profiles at various pre-programmed intensities. The following profiles are available: Hill Course, Sprints, Twin Peaks, Peak, Progressive, Multi-Peaks and Ramp.


Press **HILLS** Then 




Profile		Course
Time (mm:ss)		15:00
Level		1.0

Select 1 of 7 profiles with the   keys, then press 




The following profiles are available for selection






Profile		Course
Time (mm:ss)		15:00
Level		1.0

Adjust workout time (maximum 99 min.) with the   keys, then press 

Profile		Course
Time (mm:ss)		15:00
Level		1.0

Adjust the level intensity (maximum 20) with the   keys, then press 

Time (mm:ss)		15:00
Level		1.0
Weight (lbs)		150

Enter user weight (maximum 375 lbs/ 170 kg) with the   keys, then press  to begin workout.

PROGRAM INSTRUCTIONS

Heart Rate Program

The Heart rate transmitter strap is required for this program. Refer to page 9 for a complete instructions on using the strap and to understand how to calculate your Target Heart Rate.

• Transmitter Strap Positioning



Press **HEART RATE** Then 




Time (mm:ss)	15:00
Target Heart Rate	120
Weight (lbs)	150

Adjust the workout time (maximum 99 min.)

with the   keys, then press 

Time (mm:ss)	15:00
Target Heart Rate	120
Weight (lbs)	150

Adjust the Target Heart Rate with the

  keys, then press 

Time (mm:ss)	15:00
Target Heart Rate	120
Weight (lbs)	150

Enter the user weight (maximum 375 lbs/ 170 kg)

with the   keys, then press 


to begin workout.

Random Program

The Intelli-Fit console will randomly display different workout profiles each with its own level of difficulty. The operator only has to choose the type of the profile, then select the time length of the workout and the level difficulty.

Note: The highest column of the profile represents the workout level you selected. Columns below it are percentages of the level selected.

Press **RANDOM** Then 


Profile		Random
Time (mm:ss)		15:00
Level		1.0

Select a random profile with the  

keys, then press 


PROGRAM INSTRUCTIONS

RANDOM PROGRAM CONT'D

Profile		Random
Time (mm:ss)		15:00
Level		1.0

Adjust workout time (maximum 99 min.)

with the   keys, then press 

Profile		Random
Time (mm:ss)		15:00
Level		1.0

Adjust the level intensity (maximum 20)

with the   keys, then press 

Time (mm:ss)		15:00
Level		1.0
Weight (lbs)		150

Enter user weight (maximum 375 lbs/ 170 kg)

with the   keys, then press 

to begin workout.

PROGRAM INSTRUCTIONS

Additional Key Features

SCIFIT includes extra user friendly key features that may be used during the workout.

FAN

The console contains two 3-speed cooling fans (Low, Medium, High) that can be activated by the user at anytime during the workout (fig.1).

CHANGE PROFILE

Only seen when the "Random" program is selected. It allows the user to change the workout profile on the screen at anytime during the workout (fig.2).

PAUSE CLEAR

If at anytime the user may want to pause during a workout, this may be done by pressing the [Pause/Clear] key. The screen will then minimize and provide the user three options (fig.3).

1. Continue (one dot key)

Restarts the workout at the point where the user had paused.

2. Change (two dot key)

Returns to the data entry screen where the data information previously entered can be updated.

3. Stop (six dot key)

Exits the workout and returns to the main screen.

Note:

The console will reset to the main screen after a short period of time if no selection is made.




fig.1




fig.2




fig.3

MAINTENANCE & SERVICE

Maintenance

The TC1000 is virtually maintenance free. After training always wipe down your SCIFIT exercise product. Perspiration that continuously settles on the frame, upholstery, casing and console may eventually cause rust or damage. Damage resulting from lack of maintenance is not covered under warranty.

If defective components are identified and require replacement, the equipment should be put out of service until repaired.



CAUTION

In order to maintain a safe level of operation, equipment must be inspected on a routine basis for damaged or worn parts. Failure to inspect equipment may result in injury to yourself or others.

TC1000 Maintenance Schedule

Component	When	Use	By Whom
Covers, Seat, Handlebars and console	Damp Cloth	Daily	Club Maintenance
LCD Screen	LCD TV Screen soft cleaning cloth	Weekly	Club Maintenance
Nuts and Bolts	Tighten When Necessary	Bimonthly	Club Maintenance

UNITED STATES CUSTOMER SERVICE

For assistance in the service of SCIFIT products;

phone : +1-800-745-1373

fax : +1-918-359-2045

e-mail: service@scifit.com

The Product Support department is available by means of e-mail. Voice mail service is also available 24 hours a day for recording messages to request technical support and to order replacement parts. Our mailing address is:

SCIFIT Systems Inc.
5151 S. 110th E. Ave.
Tulsa, OK 74146
USA

UK & EUROPEAN CUSTOMER SERVICE

phone : +44 1344 300022

fax: +44 1344 868838

e-mail: info@scifit.uk.com

SCIFIT LTD (UK)
Lexham House
Forest Road
Binfield
Berkshire, RG42 4HP
UK

Company Number: 5970624 (UK)

***COUNTRIES OUTSIDE OF UK & EUROPE
PLEASE USE USA CONTACT NUMBERS***

Order online 24/ 7 at www.SCIFIT.com

WARRANTY

It is very important that your SCIFIT machine is registered. This can be done online at <http://www.SCIFIT.com/warrantyregistration.shtml> or fill out and mail the registration form at the back of this manual.

SCIFIT Statement of Warranty

SCIFIT warranties new products against defective workmanship and/or materials under normal and proper use subject to the following limitations:

(a) SCIFIT's obligation to the original purchaser shall apply to:

Within the United States and Canada both parts and the cost of labor required to replace or repair a defective product for a period of one (1) year from user/dealer purchase date as documented by *warranty card and if warranty card has not been returned by user/dealer, then date of shipment from the factory. Thereafter, for a period of two (2) years, such obligation shall extend only to the supply of replacement parts or products with any labor costs associated with such replacement or repair to be at Buyer's expense. Refer to clause (e) for components outside this policy clause.

Outside the United States and Canada replace defective product with no labor for a period of three (3) years from user purchase date as documented by *warranty card and if warranty card has not been returned by user then date of shipment from factory.

***Note: Original purchaser must register their purchased products either by warranty card return, website registration or fax to activate warranty period or shipment date is extent for start of warranty period. A ninety (90) day period is to be given for warranty registration to allow stock rotation and showroom stock, thereafter the registration will be the shipment date for the start of the warranty period.**

(b) SCIFIT's obligation shall be limited to repairing or replacing defective parts. No allowance shall be granted for repairs made by Buyer without SCIFIT's prior written approval. The decision to replace or repair shall be solely at SCIFIT's discretion.

(c) SCIFIT's warranty does not apply to parts requiring replacement or repair due to normal and abnormal wear and tear, improper use, corrosion (perspiration), improper maintenance, improper installation, improper rated, grounded or dedicated electrical circuits or improper storage, nor does it apply where all or part of the product has been altered from its original state by Buyer or a third party.

(d) THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, ARISING BY LAW OR OTHERWISE INCLUDING WARRANTY OR MERCHANTABILITY OF FITNESS FOR PARTICULAR PURPOSE, AND IS IN LIEU OF ALL OTHER LIABILITIES OF SCIFIT INCLUDING DIRECT, INDIRECT, SPECIAL AND CONSEQUENTIAL DAMAGES OR PENALTIES EXPRESSED OR IMPLIED WHETHER ARISING OUT OF CONTRACT, NEGLIGENCE OR OTHER SORT.

WARRANTY

SCIFIT STATEMENT OF WARRANTY

(e) The below listed items have the following warranty coverage unless determined to be defective. These items include, but are not limited to:

Treadmills – AC5000 models only	Warranty Period
Treadmill belts	12 months
Treadmill belts decks	12 months
Treadmill structure & frame	5 years
Treadmill drive system inclusive of motor & inverter	5 years
Treadmill handrails & Handles	3 years
Treadmill heart rate grips	12 months
Treadmill water bottle holders	90 days
Treadmill trays	90 days

Rotary Products	Warranty Period
Upholstery	12 months
Saddles/seats	12 months
Rotary pedals	12 months
Rubber grips	12 months
Heart rate grips	12 months
Rotary structure & Frame	5 years
Rubber foot pads (BioFlex)	12 months
Rotary water bottle holders	90 days
Rotary trays	90 days

Accessories Products	Warranty Period
Pedal straps	Normal wear & tear
Heart rate receiver/transmitter	90 days
Low support boots	12 months
High support boots	12 months
Assist gloves	90 days
USB keys and lanyards	90 days

(f) Fires, floods, and acts of God, are not covered under this warranty.

WARRANTY

Freight and Shipping

All SCIFIT products have displayed on the outside packaging “**STOP - UPON DELIVERY INSPECT MERCHANDISE THOROUGHLY NOTING ANY DAMAGE ON RECEIVING PAPERWORK PRIOR TO SIGNING**”.

SCIFIT is not responsible for the repair or replacement of any unit or part damaged during transit or installation. The customer is responsible for inspection of each unit and part for shipping damage at time of delivery or installation and prior to signing receiving paperwork. The customer is responsible for pursuing all freight damage claims with the appropriate transit company. **If the customer signs an unqualified receipt for freight or damage goods, the customer is solely responsible for the cost of the repair or replacement for such freight damage.**

.....

Maintenance

After training, always wipe down your SCIFIT exercise product. Perspiration that continuously settles on frame, upholstery, casings and control panels may eventually cause rust or damage. Damage resulting from lack of maintenance will NOT be covered under warranty. To clean upholstery, use mild soap and warm water. Dry with a clean towel. Refer to the machine's maintenance schedule.

WARRANTY

Product Support

Assistance for the service of SCIFIT products is available by fax +1-918-359-2045. The product support department is staffed from 7 AM to 5 PM US Central Time Monday through Friday. A voicemail service is available 24 hours daily for recording messages to request technical support and to order replacement parts. Our goal is to return every voicemail call within 30 minutes of when it is placed during our normal business hours.

Please have the following information prior to calling technical support:

- *Model number of equipment*
- *Serial number of equipment*
- *Point of contact name and phone number*
- *Detailed description of symptoms encountered*

.....

Installation

SCIFIT is not responsible for the repair or replacement of any unit or part damaged during installation. The customer is responsible for inspection of each unit and part for damage at the time of installation. The customer is responsible for pursuing all damage claims with the installer.

.....

Parts Shipment

During the first 30 days warranty parts will be shipped via overnight delivery. Determination must be made before 2:00 PM US Central Time on any given weekday for next day delivery. During the remainder of the first year warranty period, parts requirements will be filled via ground shipment. The customer will have the option to request overnight or 2nd day parts shipping, but will be charged the difference between the ground shipment cost and the overnight or 2nd day cost.

WARRANTY

Return of Parts

SCIFIT is committed to continual improvement in the equipment we market. In order to meet this commitment, the rapid return of defective parts is essential. The examination of the parts by our engineering department leads to changes that insure the same problem does not re-occur. Thank you in advance for your assistance!

When requested by SCIFIT, defective parts must be returned to the SCIFIT factory within 20 days of receipt of replacement part. Otherwise SCIFIT will expect payment on the parts invoice net 30 days.

Please follow these three easy steps for returning parts.

Step 1

Keep the box and packing material in which the new parts arrived.

Step 2

A **prepaid return label** will be in the parts box for only those parts that need to be returned. If no prepaid return label is enclosed contact SCIFIT Product Support at 1-800-745-1373. When **ALL** of the parts are received and inspected at the factory, a credit will be issued for the original parts invoiced. **Attention service companies** - labor invoices will **NOT** be paid until the defective parts are returned to the factory.

Step 3

Wrap the defective part, place it in the box and affix the return label for safe return.

Service Labor

Where applicable, the SCIFIT product support personnel will arrange a local field service technician to provide field support. Every effort will be made to schedule service during 48 business hours (8 hours per business day) following notification of a problem or as soon as repair parts are available to the field service technician. Where possible, parts will be supplied in advance of the field service technicians so that the product is repaired with one call.

Purchased Parts

All purchased parts will carry a 12 month warranty. Refer to purchased parts shipments and installation for more details.

This Limited Commercial Warranty supersedes the Limited Commercial Warranty printed in the "Users Operation Manual" for all SCIFIT Systems, Inc. products.

If you have questions or require additional information, please contact SCIFIT Systems, Inc. at service@scifit.com

WARRANTY CARD



SCIFIT® Warranty Card

Register online at <http://www.SCIFIT.com/warrantyregistration.shtml> or complete this form, fold it and return it to SCIFIT. We request you send this card within 2 weeks after your equipment has been delivered to insure proper warranty registration.

Company Name _____
 Contact Name _____
 Address _____
 City/State/Zip _____
 Home Phone (____) _____ Business Phone (____) _____
 Model Purchased _____
 Date Received _____ Serial Number _____
 Entity Purchased From _____
 City/State _____

Please rank the following reasons (1 through 6) for selecting SCIFIT with 1 being most important:

____ Features ____ Quality ____ Price ____ Dealer ____ User Friendly ____ Appearance

Please Check the appropriate box(es) on how you were introduced to SCIFIT:

Saw in _____ Magazine Introduced by SCIFIT Dealer
 Saw at _____ Tradeshow Referred by SCIFIT User
 Other _____
 Comment _____

Thank You For Choosing



Scientific Solutions for Fitness.

www.SCIFIT.com

P2278 Rev. B

SCIFIT Systems Inc.
5151 South 110th East Avenue
Tulsa, OK 74146

From _____

Important: Please keep this page for your records

Model Number: _____

Serial Number: _____

Date of Purchase: _____

**Manufactured By: SCIFIT Systems Inc.
User Manual; #P5013A (12/2011)**



Scientific Solutions For Fitness™

Order online 24/ 7 at www.SCIFIT.com